



TEKTELIC Communications Inc.  
7657 10th Street NE Calgary, Alberta  
Canada, T2E 8X2

---

## TEKTELIC COMMUNICATIONS INC.

---

Document Type: **Technical Reference Manual**

Document Number: **T0006377\_TRM**

Document Version: **0.5**

Product Name: **Kona LoRa IoT Meeting Room Display Tablet**

Product Codes: **T0006086 –Battery Powered Digital Signage**

**T0006093 – Externally Powered Digital Signage**

---

### **PROPRIETARY:**

The information contained in this document is the property of TEKTELIC Communications Inc. Except as specifically authorized in writing by TEKTELIC, the holder of this document shall keep all information contained herein confidential, and shall protect the same in whole or in part from disclosure to all third parties.

© 2019 TEKTELIC Communications Inc., all rights reserved.

All products, names, and services are trademarks and registered trademarks of their respective companies.

### **DISCLAIMER:**

Material contained in this document is subject to change without notice. The material herein is solely for information purposes and does not represent a commitment by TEKTELIC or its representatives. TEKTELIC has prepared the information contained in this document solely for use by its employees, agents, and customers. Dissemination of this information and/or concepts to other parties is prohibited without the prior written consent of TEKTELIC. In no event will TEKTELIC be liable for any incidental or consequential damage in connection with the furnishing, performance or use of this material.

TEKTELIC reserves the right to revise this publication in accordance with formal change control procedures defined by TEKTELIC.

**TEKTELIC Communications Inc.**  
**7657 10<sup>th</sup> Street NE**  
**Calgary, AB, Canada T2E 8X2**  
**Phone: (403) 338-6900**

## Revision History

Version	Date	Editor	Comments
0.1	May 23, 2018	Maulin Lodhia	First draft
0.2	May 28, 2018	Maulin Lodhia	Addressed review comments
0.3	May 30, 2019	Maulin Lodhia	Updated sections: 2.2, 3.1.3.2, 3.1.2.3 High level update: Now following downlink acknowledgement from the booking is followed by a get room status response message <ul style="list-style-type: none"><li>• Book now response</li><li>• Extend meeting response</li><li>• Book meeting in future response</li></ul>
0.4	July 19, 2019	Maulin Lodhia	Updated section 3.1.3.4 <ul style="list-style-type: none"><li>• Added a byte for total capacity</li></ul>
0.5	Nov 15, 2019	C Karperien	Template Updates and adding Product Codes
0.6	Feb 5, 2020	C Karperien	Changed product name

## Table of Contents

List of Tables .....	4
List of Figures .....	5
Acronyms and Glossary.....	6
1 Overview.....	8
2 UL Payload Formats.....	10
2.1 Frame Payload to Report Transducers Data .....	10
2.1.1 Example Uplink Payloads .....	10
2.2 Frame Payload to Request Booking Application messages .....	10
3 DL Payload Formats.....	13
3.1 Configuration and Control Commands .....	13
3.1.1 LoRaWAN Commissioning.....	14
3.1.2 LoRaMAC Configuration.....	14
3.1.3 Digital Sign Sensor Application Configuration .....	16
3.1.4 Digital Sign Sensor Command and Control.....	22
3.1.5 Preventing Sensor Bricking .....	23
References .....	25

## List of Tables

Table 1-1: Kona Digital Sign Sensor Models .....	8
Table 2-1: UL Frame Payload Values for Transducers Data .....	10
Table 3-2: LoRaWAN Commissioning Registers .....	14
Table 3-3: LoRaMAC Configuration Registers .....	14
Table 3-4: Default Values of LoRaMAC Configuration Registers .....	15
Table 3-5: Maximum Tx Power in Different Regions by Default .....	16
Table 3-6: Default Values of Rx2 Channel Frequency and DR Number in Different Regions .....	16
Table 3-7: Ticks Configuration for Periodic Tx .....	16
Table 3-7: Sensor Command & Control Register .....	22
Table 3-8: LoRaMAC Regions and Region Numbers .....	23

## List of Figures

Figure 2-1: The UL frame payload format.....	10
Figure 3-1: The format of a DL configuration and control message block. ....	13

## Acronyms and Glossary

<b>ABP</b>	activation by personalization
<b>ADR</b>	adaptive data rate
<b>bps</b>	bits per second
<b>CN</b>	China as an RF region for LoRaWAN
<b>CRC</b>	cyclic redundancy check
<b>DL</b>	downlink
<b>DN</b>	a special LoRaWAN RF region considered for Dish Network Corporation
<b>DR</b>	data rate
<b>EIRP</b>	effective isotropic radiated power
<b>EU</b>	European Union as an RF region for LoRaWAN
<b>Flash memory</b>	Non-volatile memory located on the Home Sensor, which contains application and configuration settings.
<b>FW</b>	firmware
<b>Industrial Sensor</b>	a Kona LoRa IoT Industrial Sensor module
<b>ID</b>	identity / identifier
<b>IoT</b>	Internet of things
<b>ISM</b>	industrial, scientific, and medical
<b>LoRa</b>	a patented “long-range” IoT technology acquired by Semtech
<b>LoRAMAC</b>	LoRaWAN MAC
<b>LoRaWAN</b>	LoRa wide area network (a network protocol based on LoRa)
<b>LoRaWAN Commissioning</b>	the unique device identifiers and encryption keys used for LoRaWAN communication (see LoRaWAN Specification [1] for more details).
<b>LSB</b>	least significant bit
<b>LTC</b>	lithium thionyl chloride (the chemistry of LTC batteries)
<b>MAC</b>	medium access control
<b>MCU</b>	microcontroller unit
<b>ms</b>	millisecond(s)
<b>MSB</b>	most significant bit
<b>NA</b>	North America as an RF region for LoRaWAN
<b>NS</b>	network server
<b>OTA</b>	over-the-air
<b>OTAA</b>	OTA activation
<b>Reg</b>	register
<b>RH</b>	relative humidity
<b>RF</b>	radio frequency

**RFU**..... reserved for future use  
**RO**..... read-only  
**RTU**..... remote terminal unit  
**R/W**..... read/write  
**Rx** ..... receiver  
**Sensor** ..... = Industrial Sensor  
**SW**..... software  
**transducer**..... the sensing element attached to the Industrial Sensor, e.g. the temperature and RH transducer.  
**TRM**..... technical reference manual  
**Tx**..... transmitter  
**UL** ..... uplink

# 1 Overview

This TRM describes the configuration options supported by the Digital Sign Sensor. This document is intended for a technical audience, such as application developers, with an understanding of the NS and its command interfaces.

This TRM is only applicable to the Digital Sign Sensor modules listed in Table 1-1.

The Digital Sign Sensor is an all-purpose LoRaWAN IoT sensor run on four AAA batteries and packed into a small casing. The Digital Sign Sensor features EPD screen, LCD controller, LED controller, accelerometer and battery monitor (Coulomb counter, Buck boost). The battery lifetime of the Digital Sign Sensor is estimated to be 1 year.<sup>1</sup> Table 1-1 presents the currently available Digital Sign Sensor models.

**Table 1-1: Kona Digital Sign Sensor Models**

Product Code & Revision	Description	RF Region
<b>T0006086</b>	MODULE, DIGITAL SIGNAGE, BATTERY POWERED	US 902-928 MHz (ISM band) & EU 863-870 MHz (ISM band)
<b>T0006093</b>	MODULE, DIGITAL SIGNAGE, EXTERNALLY POWERED	US 902-928 MHz (ISM band) & EU 863-870 MHz (ISM band)

Information streams currently supported by the SW are as follows:

- UL stream, i.e. from the Sensor
  - Readings obtained from on-board transducers (**sent on LoRaWAN port 10**)
  - Response to configuration and control commands from the NS (**sent on LoRaWAN port 100**)
- DL stream, i.e. data from the NS
  - Changing the state of the Sensor's (digital) outputs, i.e. open/close them (**sent on LoRaWAN port 10**)
  - Configuration and control commands used to change the Sensor's behavior (**sent on LoRaWAN port 100**)

The default configuration of the Digital Sign Sensor for reporting transducer readings includes the following:

---

<sup>1</sup> This is for transmission at maximum power every 15 minutes at room temperature, with an LTC battery having a nominal capacity of 19 Ah and self-discharge rate of 0.7%. Large variations to this estimate can occur depending on the ambient temperature, amount of usage, battery capacity, and battery self-discharge rate. For example, continuously being at -30°C and transmitting at maximum power every 30 seconds, the same battery may not last above a year.

- Report the battery voltage every 1 (one) hour.
- For Class A mode operation query room status every 5 minutes.

The Digital Sign Sensor has a USB based UART port used for debugging purposes

Also, the default configuration for the Digital Sign Sensor serial port is as follows:

- Protocol RS232
- Baud rate 115200 bps
- 8 Data Bits, No Parity Bits, 1 Stop Bit

## 2 UL Payload Formats

The UL streams (from the Sensor to the NS) supported by the SW include,

- The readings obtained from on-board transducers (sent on LoRaWAN port 10); and are explained in Sections 2.1.
- Booking Application messages.

The above streams are explained in Section Sections 2.1.and 2.2.

### 2.1 Frame Payload to Report Transducers Data

Each data field from the Sensor is encoded in a frame format shown in Figure 2-1. A big-endian format (MSB first) is always followed.




Figure 2-1: The UL frame payload format.

A Sensor message payload can include multiple transducer data frames. Frames can be arranged in any order. A single payload may include data from any given transducer. The Digital sign Sensor frame payload values for transducers data are shown in Table 2-1. Transducers data in the UL are sent through **LoRaWAN port 10**.

Table 2-1: UL Frame Payload Values for Transducers Data


Information Type	Data Channel	Data Type	Data Size [Bytes]	Data Type	Data Format
Battery Voltage	0x40	0xFF	2	Analog Input	Signed, 0.01 V/LSB
MCU Temperature	0x41	0x67	2	Temperature	0.1°C / LSB (signed)

#### 2.1.1 Example Uplink Payloads

- 0x **40 FF** 01 2C **03 67** 00 0A
  - 0x **40 FF** (Battery Voltage) = (0x 01 2C) × 0.01 V = 3.00 V
  - 0x **42 67** (MCU Temperature) = (0x 00 0A) × 0.1°C = 1°C

### 2.2 Frame Payload to Request Booking Application messages

Each data field from the Sensor is encoded in a frame format shown in Figure 2-12. A big-endian format (MSB first) is always followed.



**Figure 2-2: The UL frame payload format to request Booking App messages.**

The Digital sign Sensor frame payload values for EPD soft button presses are shown in Table 2-12.

**Table 2-2: UL Frame Payload Values request Booking App messages.**

Information Type	Message ID	Data Size [Bytes]	Data Format
Room status request	0x33	0	
Book now request	0x34	3	Book meeting room for X minutes/hour Data value: <ul style="list-style-type: none"> <li>• 0x1 = 15 minutes</li> <li>• 0x2 = 30 minutes</li> <li>• 0x3 = 45 minutes</li> <li>• 0x4 = 1 Hour</li> </ul>
Extend meeting request	0x35	3	Book meeting room for X minutes/hour Data value: <ul style="list-style-type: none"> <li>• 0x1 = 15 minutes</li> <li>• 0x2 = 30 minutes</li> <li>• 0x3 = 45 minutes</li> </ul>
Book meeting in future request	0x36	3	Book meeting room for X minutes/hour Data value: <ul style="list-style-type: none"> <li>• 0x1 = 30 minutes</li> <li>• 0x2 = 45 minutes</li> <li>• 0x3 = 1 Hour</li> </ul>
Finish Meeting	0x37	0	
Room information request	0x38	0	
Room amenities status request	0x39	1	Request status of amenities in the room Data value: <ul style="list-style-type: none"> <li>• Bit 0 – TV status</li> <li>• Bit 1 – Projector</li> <li>• Bit 2 – Web Camera</li> </ul>

			<ul style="list-style-type: none"><li>• Bit 3 – White Board</li></ul>
--	--	--	---

### 3 DL Payload Formats

The DL streams (from the Sensor to the NS) supported by the SW include,


- Configuration and control commands used to change the Sensor’s behavior (sent on LoRaWAN port 100); and are explained in Sections **Error! Reference source not found..**

#### 3.1 Configuration and Control Commands

A single DL configuration and control message can contain multiple command blocks, with a possible mix of read and write commands. Each message block is formatted as shown in Figure 3-1. A big-endian format (MSB first) is always followed.

The Command Field has a “register” address that is used to access various configuration parameters. These addresses are bound between 0x00 and 0x7F.

Bit 7 of the Command Field determines whether a read or write action is being performed. To write to a register, this bit must be set to 1 (one), but to read a register, it must be set to 0 (zero). All read commands are one-byte long. Data following a read access command will be interpreted as a new command block. Read commands are processed last. For example, in a single DL message, if there is a read command from a register and a write command to the same register, the write command is executed first.



**Figure 3-1: The format of a DL configuration and control message block.**

All DL configuration and control commands are sent on **LoRaWAN port 100**.

#### Examples:

In the following examples, the Command Field is boldfaced:

- Read Reg 0x00, 0x01, 0x02:
  - DL command: { 0x **00 01 02** }
- Read Reg 0x05 and write value 0x8000 to Reg 0x10:
  - DL command: { 0x **05 90** 80 00 }

When a write command is sent to the Sensor, the Sensor will immediately respond with a CRC32 of the entire DL payload as the first 4 bytes of the UL frame.

DL configuration and control commands fall into one of the following 4 (four) categories and are discussed in Sections 3.1.1, 3.1.2, 0, and 3.1.3.4, respectively:

- LoRaWAN Commissioning
- LoRaMAC Configuration
- Sensor Application Configuration
- Sensor Command and Control

### 3.1.1 LoRaWAN Commissioning

LoRaWAN commissioning values can be read back from the Sensor using DL commands. These registers are RO. See LoRaWAN 1.0.3 specification [1] for description of the values. Table 3-1 shows a list of these registers.

**Table 3-1: LoRaWAN Commissioning Registers**

Address	Access	Value	# Bytes
0x00	R	DevEUI	8
0x01	R	AppEUI	8
0x02	R	AppKey	16
0x03	R	DevAddr	4
0x04	R	NwkSKey	16
0x05	R	AppSKey	16

**Note 1:** Commissioning values need to be kept secure at all times.

**Note 2:** Registers 0x02, 0x04, 0x05 cannot be read back in some regions if the DR number is too small. For example, in the NA region, the maximum frame payload size with DR0 is 11 bytes.

### 3.1.2 LoRaMAC Configuration

LoRaMAC options can be configured using DL commands. These configuration options change the default MAC configuration that the Sensor loads on start-up. They can also change certain run-time parameters. Table 3-2 shows the MAC configuration registers. In this table,  $B_i$  refers to data byte indexed  $i$  as defined Figure 3-1.

**Table 3-2: LoRaMAC Configuration Registers**

Address	Access	Value	# Bytes	Description
0x10	R/W	Join Mode	2	B <sub>0</sub> -bit 7: 0 = ABP, 1 = OTAA B <sub>1</sub> : RFU
0x11	R/W	<ul style="list-style-type: none"> <li>• Unconfirmed/Confirmed UL</li> <li>• Disable/Enable Duty Cycle</li> <li>• Disable/Enable ADR</li> </ul>	2	B <sub>0</sub> -bits 7–4: 0 = Class A, C = Class C B <sub>1</sub> -bit 0: 0 = Unconfirmed UL, 1 = Confirmed UL B <sub>1</sub> -bit 2: 0 = Disable duty cycle, 1 = Enable duty cycle

				B <sub>1</sub> -bit 3: 0 = Disable ADR, 1 = Enable ADR
0x12	R/W	<ul style="list-style-type: none"> <li>• Default DR number</li> <li>• Default Tx Power number</li> </ul>	2	B <sub>0</sub> -bits 3–0: Default DR number [2] B <sub>1</sub> -bits 3–0: Default Tx power number [2]
0x13	R/W	<ul style="list-style-type: none"> <li>• Rx2 window DR number</li> <li>• Rx2 window channel frequency</li> </ul>	5	B <sub>0</sub> -B <sub>1</sub> -B <sub>2</sub> -B <sub>3</sub> : Channel frequency in Hz for Rx2 B <sub>4</sub> : DR for Rx2
0x19	R/W	Net ID MSBs	2	Bytes B <sub>0</sub> -B <sub>1</sub> in the Net ID (B <sub>0</sub> -B <sub>1</sub> -B <sub>2</sub> -B <sub>3</sub> )
0x1A	R/W	Net ID LSBs	2	Bytes B <sub>2</sub> -B <sub>3</sub> in the Net ID (B <sub>0</sub> -B <sub>1</sub> -B <sub>2</sub> -B <sub>3</sub> )

**Note:** Modifying these values only changes them in the Sensor device. Options for the Sensor in the NS also need to be changed in order to not strand a Sensor. Modifying configuration parameters in the NS is outside the scope of this document.

**Examples:**

In the following example payloads, the Command Field is boldfaced:

- Switch Device to ABP Mode:
  - DL payload: { 0x **90** 00 00 }
- Set ADR On, No Duty Cycle, and Confirmed UL Payloads:
  - DL payload: { 0x **91** 00 09 }
- Set default DR number to 1 and default Tx Power number to 2:
  - DL payload: { 0x **92** 01 02 }

**3.1.2.1 Default Configuration**

Table 3-3 and Table 3-5 list the default values for the LoRaMAC configuration registers (cf. [1], [2]).

**Table 3-3: Default Values of LoRaMAC Configuration Registers**

Address	Default Value
0x10	0x 80 00 (OTAA mode)
0x11	0x 00 0C (Class A, Unconfirmed UL, enabled duty cycle, enabled ADR)
0x12	0x 00 04 (DR0, Tx Power 0—max power, see Table 3-4)
0x13	As per Table 3-5.
0x19	0x 00 00
0x1A	0x 00 00

**Table 3-4: Maximum Tx Power in Different Regions by Default**

RF Region	Max Tx EIRP [dBm]
EU868	16
US915	30
AS923	16
AU915	30
IN865	30
CN470	19.15
KR920	14
RU864	16

**Table 3-5: Default Values of Rx2 Channel Frequency and DR Number in Different Regions**

RF Region	Default Value	Channel Frequency	DR Number
EU868	0x 33 D3 E6 08 00	869.525 MHz	DR0
NA915	0x 37 08 70 A0 08	923.3 MHz	DR8
AS923	0x 37 06 EA 00 02	923.2 MHz	DR2
AU915	0x 37 08 70 A0 08	923.3 MHz	DR8
IN865	0x 33 A6 80 F0 02	866.55 MHz	DR2
CN470	0x 1E 1E 44 20 00	505.3 MHz	DR0
KR920	0x 36 F3 13 E0 00	921.9 MHz	DR0
RU864	0x 33 CD 69 E0 00	869.1 MHz	DR0

### 3.1.3 Digital Sign Sensor Application Configuration

This section lists all possible Sensor application configurations (as part of DL configuration and control commands), like periodic Tx configuration.

**Note:** Care must be taken to avoid stranding the sensor during reconfiguration. If all sensing inputs are disabled, the device will not be able to be reconfigured.

#### 3.1.3.1 Periodic Tx Configuration

All periodic sensor reporting is synchronized around “ticks”. A tick is simply a user configurable time-base that is used to schedule sensor measurements. For each transducer, the number of elapsed ticks before transmitting can be defined, as shown in Table 3-6.

**Table 3-6: Ticks Configuration for Periodic Tx**

Address	Access	Value	# Bytes	Description
0x20	R/W	Seconds in a Tick	4	Sets the core tick in seconds for periodic events (0 disables)
0x21	R/W	Ticks per Battery Tx	2	Ticks between battery reports (0 disables)
0x22	R/W	Ticks per MCU Temperature Tx	2	Ticks between MCU temperature reports (0 disables)

0x23	R/W	Ticks per get room status request	2	Ticks between get room status request (0 disables)
------	-----	-----------------------------------	---	--

### 3.1.3.1.1 Seconds in a Tick

All periodic transmit events are schedule in “ticks”. This allows for sensor reads to be synchronized, reducing the total number of uplinks required to transmit sensor data. The minimum seconds in a tick is 30 seconds and the maximum is 86400 seconds (i.e. a day). Values from 1 to 29 or above 86400 are RFU and will be ignored by the sensor.

If “Seconds in a Tick” is set to 0 (zero), **all** periodic reporting will be disabled regardless of individual sensor reporting configurations. Disabling all periodic based reporting is not recommended!

### 3.1.3.1.2 Ticks per <Transducer>

Sets the individual tick period for a transducer. Once the configured number of ticks has expired the Sensor will poll the specified transducer and report the data in an uplink message.

A setting of 0 (zero) will disable periodic reporting for the specified transducer. Disabling all periodic based reporting is not recommended!

### 3.1.3.1.3 Default Configuration

<b>Seconds in a Tick</b>	300 seconds (5 min)
<b>Ticks per Battery Tx</b>	12 (1 hour)
<b>Ticks per MCU Temperature Tx</b>	0 (disabled)
<b>Ticks per Get room Status request</b>	2 (10 min)

### 3.1.3.1.4 Example DL Messages


- Disable all periodic events:
  - 0x: A0 00 00 00 00 (Reg 20, write bit set to true) – Seconds in a Tick = 0 (disabled)
- Read the current “Seconds in a Tick” value:
  - 0x: 20 (Reg 20, write bit set to false)
- Write “Tick per MCU Temperature Tx” and “Ticks per get room status request”:
  - 0x: A2 00 01 A3 00 02 (Reg 22 and Reg 23, write bit set to true)—set “Ticks per MCU Temperature Tx” to 1 (one) and “Ticks per get room status request” to 2 (two).

### 3.1.3.2 Booking application acknowledgements

The message ID field is the response for the message UL request (as described in Table 2-2).

The message block is formatted as shown in Figure 3-13. A big-endian format (MSB first) is always followed. All the booking application acknowledgments are sent on **LoRaWAN port 101**.

NOTE: Each acknowledgement is followed by a room status response as described later section 3.1.3.3



**Figure 3-2: The format of a DL booking application acknowledgements**

The following table describes the booking application downlink acknowledgments.

**Table 3-8: DL Frame Booking Application acknowledgements.**

Information Type	Message ID Field Value	Maximum DL Frame size (Bytes)	Number of DL messages per UL message request	Information
Book now response	0xB4	1	1	ACK
	0x34	1	1	NACK
Extend meeting response	0xB5	1	1	ACK
	0x35	1	1	NACK
Book meeting in future response	0xB6	1	1	ACK
	0x36	1	1	NACK
Finish Meeting	0xB7	1	1	ACK
	0x37	1	1	NACK

### 3.1.3.3 Booking application get room status response

A single UL get room status request may result in multiple DL responses and acknowledgements. Each message block is formatted as shown in Figure 3-13. A big-endian format (MSB first) is always followed.

The message ID field is the response for the message UL request (as described in Table 2-2).

Message ID bit 7(A/N) of the message ID determines whether message is ack or nacked. For room status response, this bit determines whether room is occupied (bit value 1) or available (bit value 0).

Byte 0 (B<sub>0</sub>), bit 7 (EPD\_E) describes if EPD screen needs to be turned off. This is required for turning off the screen during off hours to save battery.

- ON (bit value of 1)
- OFF (bit value or 0)

Byte 0 (B<sub>0</sub>), bit 6 (TS\_E) describes if touch screen needs to be turned off. This is required for turning off the screen during off hours to save battery or locking the screen.

- ON (bit value of 1)
- OFF (bit value or 0)

Byte 0 (B<sub>0</sub>), bit 5 (Nx/C) describes what this DL frame contains

- Next booking information (bit value 1)

Next booking information (Nx):


- Next booking time (Byte B<sub>0</sub>, B<sub>1</sub>) HH:MM AM/PM
- Booked by string size maximum of 30 bytes.
- Booked by string - N bytes of string

- Current booking information (bit value 0).

Current booking information (C):

- Current booking Till time (Byte B<sub>0</sub>, B<sub>1</sub>): HH:MM AM/PM
- Booked by string size maximum of 30 bytes.
- Booked by string - N bytes of string

Byte B<sub>0</sub>, bit 4 determines the time is PM (bit value of 1) or AM (bit value 0)



**Figure 3-3: The format of a DL booking application get room status message block.**

The uplink booking application get room requests require response split into 2 DL frames.

First DL frame containing information of current meeting (till time, booked by) and following DL frame containing information about next meeting (next meeting book time, next meeting booked by).

The following table describes the booking application get room status downlink response message.

**Table 3-9: DL Frame Booking Application get room status response.**


Information Type	Message ID Field Value	Maximum DL Frame size (Bytes)	Number of DL messages per UL message request	Information
Room status response	0xB3	34	2	Occupied
	0x33	34	1	Available

Get room status response is sent on **LoRaWAN port 102**.

### 3.1.3.4 Booking application get room information response/acknowledgement

This message response/acknowledgement is different from regular DL booking application acknowledgments described in earlier section.

The following the DL frame format for get room information response message.



**Figure 3-4: The format of a DL booking application get room information acknowledgment message block.**

Message ID bit 7(A/N) of the message ID determines whether message is ack or nacked.

Byte 0 (B<sub>0</sub>) for this response message contains the Amenities presence bit mask

- Bit 0 – TV
- Bit 1 – Projector
- Bit 2 – Web Camera

- Bit 3 – White Board

Byte 1 ( $B_1$ ) is size of the Room name string N bytes.

Subsequent bytes is room name string of N bytes.

The following table describes the booking application get room information downlink acknowledgment.

**Table 3-9: DL Frame Booking Application get room information acknowledgement.**


Information Type	Message ID Field Value	Maximum DL Frame size (Bytes)	Number of DL messages per UL message request	Information
Room information response	0xB8	34	1	ACK
	0x38	1	1	NACK

Get room information acknowledgement/response is sent on **LoRaWAN port 103**.

### 3.1.3.5 Booking application get amenities status response

This message response/acknowledgement is different from regular DL booking application acknowledgments described in earlier section.

The following the DL frame format for get room information response message.



**Figure 3-5: The format of a DL booking application get amenities acknowledgment message block.**

Message ID bit 7(A/N) of the message ID determines whether message is ack or nacked.

Byte 0 ( $B_0$ ) for this response message contains the Amenities status bit mask

- Bit 0 – TV
- Bit 1 – Projector
- Bit 2 – Web Camera

- Bit 3 – White Board

Bit value of 1 means the amenity is at fault.

Byte 1 (B<sub>1</sub>) is size of the fault description string N bytes.

Subsequent bytes is fault description string of N bytes.

The following table describes the booking application get amenities status downlink acknowledgment. Get amenities status acknowledgement/response is sent on **LoRaWAN port 104**.

**Table 3-10: DL Frame Booking Application get amenities status acknowledgement.**

Information Type	Message ID Field Value	Maximum DL Frame size (Bytes)	Number of DL messages per UL message request	Information
Get Amenities status response	0xB9	33	1	ACK
	0x39	1	1	NACK

### 3.1.4 Digital Sign Sensor Command and Control

Configuration changes are not retained after a power cycle unless they are saved in the flash memory. Table 3-7 shows the structure of the Command and Control registers. In this table, B<sub>i</sub> refers to data byte indexed *i* as defined in Figure 3-1.

**Table 3-7: Sensor Command & Control Register**

Address	Access	Name	# Bytes	Description
0x70	W	Flash Memory Write Command	2	B <sub>0</sub> , bit 5: Write App Config B <sub>0</sub> , bit 6: Write LoRa Config B <sub>1</sub> , bit 0: Restart Sensor In all cases: 0 = De-asserted, 1 = Asserted Other bits are ignored.
0x71	R	FW Version	7	B <sub>0</sub> : App version major B <sub>1</sub> : App version minor B <sub>2</sub> : App version revision B <sub>3</sub> : LoRaMAC version major B <sub>4</sub> : LoRaMAC version minor B <sub>5</sub> : LoRaMAC version revision B <sub>6</sub> : LoRaMAC region number
0x72	W	Reset Config Registers to	1	0x0A: Reset App Config 0xB0: Reset LoRa Config 0xBA: Reset both App and LoRa Configs Any other value is ignored.

---

Factory  
Defaults<sup>2</sup>

---

**Note:** The Flash Memory Write Command is always executed after the full DL configuration message has been decoded. The reset command should always be sent as an “unconfirmed” DL message. Failure to do so may cause the NS to continually reboot the Sensor.

### 3.1.4.1 LoRaMAC Region

The LoRaMAC region is indicated by  $B_6$  in the FW Version register (Reg 0x71). Current LoRaMAC regions and corresponding region numbers are listed in Table 3-8.

**Table 3-8: LoRaMAC Regions and Region Numbers**

LoRaMAC Region	Region Number
EU868	0
NA915	1
AS923	2
AU915	3
IN865	4
CN470	5
KR920	6
RU864	7

### 3.1.4.2 Command Examples

In the following examples, the Command Field is boldfaced:

- Write application configuration to flash memory
  - DL payload: { 0x **FO** 20 00 }
- Write application and LoRa configurations to flash memory
  - DL payload: { 0x **FO** 60 00 }
- Reboot Device
  - DL payload: { 0x **FO** 00 01 }
- Read FW versions, and reset application configuration to factory defaults
  - DL payload: { 0x **71 F2** 0A }

### 3.1.5 Preventing Sensor Bricking

Care has been taken to avoid stranding (hard or soft bricking) the Sensor during reconfiguration. Hard bricking refers to the condition that the Sensor does not transmit any more as all periodic and event-based reporting (see subsequent sections) have been disabled

---

<sup>2</sup> Resetting to factory defaults takes effect on the next power cycle.

and the configuration has been saved to the Flash memory. Soft bricking refers to the condition where the Sensor has been configured such that all event-based reporting is disabled and any periodic reporting is either disabled or has a period of larger than a week. Therefore, transmissions from a soft-bricked Sensor cannot be smaller than a week apart.

To avoid these situations, for any reconfiguration command sent to the Sensor, the following algorithm is automatically executed:

After the reconfiguration is applied, if all event-based reporting (see Sections **Error! Reference source not found.** and **Error! Reference source not found.** for event-based reporting) is disabled, then periodic reporting is checked (see Section 3.1.3.1 for periodic reporting). If all periodic reporting is disabled or the minimum non-zero period is greater than a week, then to avoid bricking the Sensor, the core tick is set to 86400 (i.e. one day), and the battery voltage tick is set to 1 (one).

## References

- [1] LoRa Alliance, "LoRaWAN Specification," ver. 1.0.3, Jul 2018.
- [2] LoRa Alliance, "LoRaWAN Regional Parameters," ver. 1.1, rev. B, Jan 2018.